




## Instructions for integrating the ELWA® with ELWA Modbus Interface in Loxone Config



Before commissioning, it is essential that you read the assembly- and operating instructions of both products. They are also available on [www.my-pv.com](http://www.my-pv.com)

 Only the Miniserver Go is required for operation.

### 1. Description of Modbus RTU communication

A detailed description is in the Operation Manual of the ELWA Modbus Interface. It is also available on [www.my-pv.com](http://www.my-pv.com)

### 2. Integration of ELWA Modbus Interface in Loxone Config

Please use the predefined Template that is in this Software-Package!

Subject to change.

my-PV GmbH  
Teichstrasse 43, 4523 Neuzeug  
[www.my-pv.com](http://www.my-pv.com)